Kirk-Rudy, Inc.

Instruction and Parts Manual 211/211E Labeling Head



Manufactured by Kirk-Rudy, Inc.

Before using this machine, all operators must study this manual to understand and follow the <u>safety warnings and instructions</u>. Keep these instructions with the machine for future reference. If you have any questions, contact your local Kirk-Rudy, Inc. Distributor.

10000-211

REV. 1 08/16/99

TABLE OF CONTENTS

| SECTION | DESCRIPTION | | <u>PAGE</u> |
|---------|-------------------------|-------------------|-------------|
| 1 | IMPORTANT SAFETY INST | RUCTIONS | 3 |
| 2 | INSTALLATION | | 4 |
| | 2.1 CHANGE GEARS | | 4 |
| | 2.2 CHANGE GEAR TIMI | NG | 4 |
| | 2.3 CIRCULAR KNIFE Al | LIGNMENT | 4 |
| | 2.4 CIRCULAR KNIFE Al | DJUSTMENT | 4 |
| | 2.5 MARGINAL TRIM AI | JUSTMENT | 5 |
| | 2.6 FEEDER BELT ADJU | STMENT | 5 |
| | 2.7 LABEL BUCKLE ADJ | USTMENT | 5 |
| | 2.8 LABEL BRAKE TIMI | NG | 6 |
| | 2.9 LABEL WHEEL TIMI | NG | 6 |
| | 2.10 SETTING THE GUILL | OTINE KNIFE | 6 |
| | 2.11 SET UP FOR 3 UP LA | BEL 4.5 | 6 |
| 3 | MECHANICAL PARTS AND | DIAGRAMS | 7 |
| | 3.1 FRAME ASSEMBLY, | LABELLING HEAD | 7 |
| | 3.2 LABELING HEAD, IN | TERNAL MECHANISM | M 8 |
| | 3.3 LABEL FEEDING ME | CHANISM | 12 |
| * | 3.4 MECHANISM ASSEM | IBLY-END PLATE | 14 |
| | 3.5 FROM INDEX, LABE | LING HEAD | 16 |
| | 3.6 UPPER KNIFE LABEI | LING HEAD | 18 |
| | 3.7 LABEL & MARGIN S | LITTER ASSEMBLY | 19 |
| | | LY, LABELING HEAD | 20 |
| 4 | KR 211E LABELING HEAD | | 22 |
| | 5.1 ELECTRONIC INDEX | ER | 22 |
| | 5.2 LABEL SIZE CHART | | 22 |
| | 5.3 PROBLEM DIAGNOS | TIC GUIDE | 23 |
| | 5.4 PROBLEM DIAGNOS | TICS | 24 |
| | 5.5 PARTS & DIAGRAMS | • | 25 |
| 5 | NOTES | | 26 |
| 6 | WARRANTY AND SERVICE | INFORMATION | BACK COVER |

NOTE: FIGURES AND DIAGRAMS ARE NOT INCLUDED IN PAGE NUMBERS.

1 Important Safety Instructions

SAVE THESE INSTRUCTIONS. Read all instructions before using this product.



WARNING

- * NEVER OPERATE THE MACHINE WITHOUT ALL GUARDS OR SAFETY DEVICES IN PLACE.
- * ALWAYS TURN POWER OFF WHEN MAKING ADJUSTMENTS.
- * ALWAYS DISCONNECT THE POWER SUPPLY BEFORE ANY MAINTENANCE OR SERVICE WORK.
- * NEVER START THE MACHINE WITHOUT FIRST CHECKING ALL PERSONNEL ARE CLEAR OF MOVING PARTS.
- * KEEP FINGERS CLEAR OF ALL MOVING PARTS.
- * NEVER REMOVE THE PRODUCT FROM THE MACHINE WHILE MACHINE IS RUNNING.
- * SHOULD MISFED PRODUCT JAM THE MACHINE AND STOP IT FROM RUNNING, ALWAYS PRESS THE STOP BUTTON BEFORE CLEARING PRODUCT. IF THE STOP BUTTON IS NOT PRESSED AND THE JAM IS CLEARED, THE MACHINE WILL BEGIN RUNNING.
- * IT IS NOT RECOMMENDED THAT LOOSE CLOTHING, JEWELRY AND LONG HAIR BE WORN WHILE OPERATING THIS MACHINERY.
- * ALWAYS USE AN EXPERIENCED ELECTRICIAN WHEN TROUBLE-SHOOTING ELECTRICAL PROBLEMS.
- * CHANGES OR MODIFICATIONS TO THIS UNIT NOT EXPRESSLY APPROVED BY THE PARTY RESPONSIBLE FOR COMPLIANCE COULD VOID THE USER'S AUTHORITY TO OPERATE THE EQUIPMENT.

<u>NOTE:</u> THIS EQUIPMENT HAS BEEN TESTED AND FOUND TO COMPLY WITH THE LIMITS FOR A CLASS A DIGITAL DEVICE, PURSUANT TO PART 15 OF THE FCC RULES. THESE LIMITS ARE DESIGNED TO PROVIDE REASONABLE PROTECTION AGAINST HARMFUL INTERFERENCE WHEN RADIO FREQUENCY ENERGY AND, IF NOT INSTALLED AND USED IN ACCORDANCE WITH THE INSTRUCTION MANUAL, MAY CAUSE HARMFUL INTERFERENCE TO RADIO COMMUNICATIONS. OPERATION OF THIS EQUIPMENT IN A RESIDENTIAL AREA IS LIKELY TO CAUSE HARMFUL INTERFERENCE IN WHICH CASE THE USER WILL BE REQUIRED TO CORRECT THE INTERFERENCE AT HIS OWN EXPENSE. SHIELDED CABLES MUST BE USED WITH THIS UNIT TO ENSURE COMPLIANCE WITH THE FCC CLASS A LIMITS.

2 INSTALLATION

2.1 Change Gears

The KR Model 211 computer label head comes equipped with 3, 4, and 5 across gears as standard equipment. Gears are mounted (while facing rear of machine) as follows:

3 across – both gears are the same size and can be mounted on either shaft.

4 across – large gear to the left, small gear to the right.

5 across – large gear to the left, small gear to the right.

NOTE: In most cases the gears will be stamped: e.g. 5L

2.2 Change Gear Timing (Refer to Figure 1)

Rotate the machine by hand until 105905 feeder belt has just stopped. The feeder belt operates on a start/stop motion – change gear timing requires that the belt has just stopped. Remove both change gears presently mounted on the machine and install one of the desired gears – either the right or left change gear. By hand, rotate the 501014 cam bracket (do not loosen the bracket retaining screw) counterclockwise until the upper guillotine knife begins its downward travel and makes contact with the lower guillotine knife approximately 5 ½" from the right (while facing the front of the machine) edge – this position will be between the 4th and 5th hex head bolt that mounts the upper guillotine knife. At this point install the second change gear – the 501014 cam bracket can be pivoted slightly until change gear teeth are meshed.

2.3 Circular Knife Alignment

The 500967 shaft contains a 1/10" scale denoting various label sizes. The most common sizes (2.6", 2.8", and 3.4") are etched into the entire width of the scale and would enable you to position all the circular knife assemblies in alignment with these label sizes. To adjust for label lengths other than the aforementioned, position the right (while facing the rear of the machine) circular knife assembly to the desired label length and measure for label length between the remaining circular knives.

NOTE: The circular knife assemblies are positioned with the right (while facing rear of machine) 103203 bushing aligned with the desired label length etched into the scale.

2.4 Circular Knife Adjustment

Turn all the top adjusting knobs on the 500965 knife levers counter-clockwise to their respective stops. Loosen the bottom (locking) knobs and pivot knives away from the 501029 hub assemblies. Loosen the allen set screws retaining the 501029 hub assemblies and locate all the hubs until approximately centered with their respective circular knives. Circular knife pressure is adjusted as follows:

- A. Marginal trim knives pivot knife assembly toward 501053 pin wheel hub until 102704 spring is compressed approximately half the total distance at this point tighten lower (locking) hand knob and turn top (adjusting) hand knob approximately 3 turns clockwise. It is important that the marginal trim knives cut the paper clean through.
- B. Internal knives pivot knife assembly toward 501029 hub until 102704 spring is <u>slightly</u> compressed at this point tighten lower (locking) hand knob and turn top (adjusting) hand approximately 2 turns clockwise or until desired cut

is achieved. Ideally the internal knives should not cut the paper clean through but would leave the entire label strip slightly enjoined.

2.5 Marginal Trim Adjustment

Horizontal location of computer address label formats will vary thereby requiring minor adjustments for proper marginal trim. Determine if the address labels will be run through the machine head-first or foot-first and adjust for trim as follows:

- A. Pencil a vertical line .2" in front of the first printed character on label #1.
- B. Traverse the 501053 pin wheel hub on its shaft until its respective marginal trim knife is aligned with the pencil marking.
- C. Align opposite 501053 pin wheel hub for width of computer form: at this point both sets of pins should be centered with feed holes on computer form.
- D. Positions 500984 paper stripper guides so one time is located inside the slot in 501053 pin wheel hub. Do not overtighten stripper guide retaining screws.

NOTE: Prior to putting "live" list in machine it is recommended to thread a blank piece of computer paper a few inches beyond the circular knives: remove from machine a superimpose on "live" list sheet to check for proper trim and label length alignment.

2.6 Feeder Belt Adjustment

The 105905 feeder belt must travel approximately the same distance as the label length: e.g., 4 across, 3.4" format, the feeder belt should travel 3.4".

TO CHECK: Rotate the machine by hand until the feeder belt just stops. Pencil a line on the belt adjacent to the line stamped in the 500909 feeder bar, or O position. Continue to rotate the machine by hand until the belt just stops – at this point the pencil line should be aligned with the required label length numeral(s) stamped in the feeder.

TO ADJUST: Loosen 10x32 allen set screw in 500979 hub – this will permit you to turn the hub's 1/4x20 allen cap screw. Turn cap screw counterclockwise to lengthen belt stroke and clockwise to shorten stroke.

IMPORTANT: Feeder belt travel must always be checked when belt has momentarily stopped and from the O position stamped in the feeder bar. Maintain rigid tension on feeder belt at all times – this is accomplished by loosening the 1/4x20 allen screw retaining 501907 hub assembly and pivoting hub for required belt tension.

2.7 Label Buckle Adjustment (Refer to Figure 2)

Loosen allen set screw that retain the 501031 roller and 501051 brake cam to their respective shafts. Rotate 501031 roller is high point is straight up and not in contact with 500986 spacer roller. Turn 501051 brake cam until 500998 lever is at the high point (500986 spacer roller will be contacting 501048 guide plate). Hold 501031 roller and 501051 brake cam in the aforementioned position. With labels on feeder belt, rotate machine by hand until lead edge of label contacts 500986 spacer roller – continue to rotate machine until label buckles approximately ½" to $^3/_8$ "; at this point turn 501031 clockwise until its high point just makes contact with 500986 spacer roller – tighten roller set screw.

2.8 Label Brake Timing (Refer to Figure 3)

The 501051 brake cam (with set screw still loose) should continue to be held in the position explained in "Label Buckle Adjustment". Rotate machine until 501031 roller is within ¼" of rotating off its high point – turn 501051 brake cam clockwise until its high point just begins to depress 500998 laver or rear edge of label is released and tighten brake cam set screw. Exercise caution when making this adjustment as only slight movement of 500998 lever will be noticable when depressed by brake cam.

2.9 Label Wheel Timing

The lead edge of the label should fall approximately 1/32" to 1/16" from the lead edge of 500918 pad. To adjust, loosen 1/4x20 allen screw in 500911 wheel hub and rotate wheel to desired position.

2.10 Setting the Guillotine Knife

NOTE: All right and left are as you stand on operators side of the machine.

- 1. Remove all knock downs behind the upper knife.
- 2. Remove upper knife from head.
- 3. Remove right hand gib.
- 4. Remove lower knife
- 5. Rotate lower knife or replace with sharp knives and tighten all screws just finger tight.
- 6. Put right hand gib back on the machine.
- 7. Put upper knife on the head. To do this put the right hand side of the upper knife down even with the lower knife and tighten one gib screw on the right side. Put 5/32 allen wrench between the upper and lower knife all the way on the left side. Remove allen wrench and bring down just a little more. A 1/8 allen wrench should now just fir in between the upper and lower knife, if a 5/32 will still fit you need to come down a little further yet. Now tighten the gib screw on the left side.
- 8. Push upper knife down and tighten gib screw so knife is held down. Loosen the gib screw until the upper knife pops up, repeat until all six screws are adjusted.
- 9. Adjust the lower knife on the left side so the knife will cut.
- 10. Now adjust the right hand side too so the right side of the knife will cut.
- 11. Before you adjust knives remove the gib screws so the upper knife will move freely.
- 12. Remove the upper knife casting and tighten buttonhead screws on the lower knife from the center out.
- 13. Put the upper knife back in and repeat the setting of the angle or lead.
- 14. Adjust from right to left on lower knife so the full length of the knife is cutting. Always keep ahead of your cut when you are making adjustments.

2.11 Set-up for 3-up Label 4.5

Put first circular knife on, 2.7 on circular knife shaft scale. Put ¼-20 bolt in upper hole on aluminum arm close to grit wheel. Set stroke on 4.5.

Raise the little rubber roller so it will just clear the belt. The label will not have any blister in it at the pick up point. Adjust cam behind pick up wheel so label can be picked off by vacuum wheel.






FIGURE 1






3 PARTS LISTS AND DIAGRAMS

3.1 FRAME ASSEMBLY, LABELING HEAD

| Item | Qty | Part # | Description |
|------|-----|----------|---------------------------|
| 1 | 1 | 500903 | PLATE, FRONT |
| 2 | 2 | 501022 | SPACER, FRAME |
| 3 | 1 | 100304 | BUSHING |
| 4 | 2 | 107417 | SCREW, CAP (10-32x3/8) |
| 5 | 1 | 100315 | BUSHING |
| 6 | 12 | 103108 | BEARING |
| 7 | 9 | 107407 | SCREW, 1/4-20 x 1 |
| 8 | 2 | 103120 | BEARING, BALL |
| 9 | 3 | 103116 | BEARING, BALL |
| 10 | 2 | 100325 | BUSHING, BRONZE |
| 11 | 1 | 501001 | BLOCK, SPACER |
| 12 | 1 | 501023 | HUB, BEARING |
| 13 | 1 | 501032 | HUB, BEARING |
| 14 | 2 | 103112 | BEARING, BALL |
| 15 | 2 | 100321 | BUSHING, BRONZE |
| 16 | 2 | 109610 | CUP, OIL |
| 17 | 1 | 500906-1 | PLATE, CENTER |
| 18 | 9 | 107401 | SCREW, CAP (1/4-20 x 3/4) |
| 19 | 1 | 500902 | PLATE, REAR |
| 20 | 1 | 500907-1 | PLATE, END |
| 21 | 1 | 501061 | BAR, REST |
| 22 | 1 | 103109 | BEARING |
| 23 | 2 | 190638 | CUP, OIL |




3.2 LABELING HEAD, INTERNAL MECHANISM

| Item | Qty | Part # | Description |
|------|-----|--------|--|
| 1 | 1 | 500997 | ARM, VACUUM DISC |
| 2 | 2 | 100606 | WASHER |
| 3 | 2 | 107429 | SCREW, CAP(10-32 x 5/8) |
| 4 | 4 | 106800 | SCREW BUTTON HD($1/4-20 \times 3/4$) |
| 5 | 1 | 500922 | DISC |
| 6 | 1 | 190604 | NIPPLE |
| 7 | 3 | 107645 | SCREW, SET (5/16-18 x 3/8) |
| 8 | . 3 | 102212 | COLLAR |
| 9 | 1 | 500911 | WHEEL |
| 10 | 1 | 500918 | PAD |
| 11 | 9 | 107633 | SCREW, SET (1/4-20 x 1/4) |
| 12 | 1 | 500923 | PAD |
| 13 | 1 | 500975 | SHOE |
| 14 | 1 | 500976 | CLAMP |
| 15 | 1 | 107437 | SCREW, CAP (6-32 x 3/8) |
| 16 | 2 | 107425 | SCREW, CAP (1/4-20 x 1 ³ / ₄) |
| 17 | 1 | 105314 | KEY |
| 18 | 3 | 105304 | KEY |
| 19 | 1 | 500935 | SHAFT |
| 20 | 1 | 500977 | SHAFT |
| 21 | 1 | 105324 | KEY |
| 22 | 1 | 500985 | SHAFT |
| 23 | 1 | 105332 | KEY |
| 24 | 3 | 106704 | NUT |
| 25 | 1 | 501031 | ROLLER |
| 26 | 1 | 107635 | SCREW, SET (1/4-20 x 3/8) |
| 27 | 15 | 107623 | SCREW, SET (10-32 x 1/4) |
| 28 | 1 | 501051 | CAM |
| 29 | 1 | 105310 | KEY |
| 30 | 1 | 500980 | SHAFT |
| 31 | 1 | 500979 | HUB |
| 32 | 2 | 107601 | SCREW, SET (6-32 x 3/16) |
| 33 | 1 | 500992 | BLOCK |
| 34 | 1 | 500952 | CRANK |
| 35 | 1 | 103106 | BEARING |

| Item | _Qty_ | Part # | Description |
|------|-------|--------|-------------------------------|
| 36 | 1 | 107100 | SCREW SHOULDER |
| 37 | 2 | 107621 | SCREW, SET (10-32 x 1/8) |
| 38 | 1 | 501009 | SPROCKET |
| 39 | 2 | 102209 | COLLAR |
| 40 | 3 | 100605 | WASHER |
| 41 | 2 | 107404 | SCREW, CAP (1/4-20 x 1 ½) |
| 42 | 2 | 106721 | NUT |
| 43 | 1 | 500949 | ROD |
| 44 | 1 | 103501 | BEARING |
| 45 | 2 | 107401 | SCREW, CAP (1/4-20 x 3/4) |
| 46 | 1 | 500954 | CRANK |
| 47 | 1 | 501025 | SPACER |
| 48 | 1 | 500945 | SHAFT |
| 49 | 5 | 105306 | KEY |
| 50 | 8 | 104106 | RING SNAP |
| 51 | 1 | 101100 | BEARING, ONE WAY |
| 52 | 1 | 500960 | PULLEY |
| 53 | 1 | 105405 | PIN, DOWEL |
| 54 | 1 | 500981 | SHAFT |
| 55 | 4 | 107622 | SCREW, SET(10-32 x 3/16) |
| 56 | 1 | 500903 | PLATE, FRONT |
| 57 | 1 | 102319 | SPACER |
| 58 | 1 | 501005 | GEAR ASSEMBLY |
| 59 | 2 | 107408 | SCREW, CAP $(10-32 \times 1)$ |
| 60 | 1 | 102318 | SPACER |
| 61 | 16 | 103108 | BEARING |
| 62 | 1 | 501011 | SPROCKET |
| 63 | 1 | 102317 | SPACER |
| 64 | 2 | 401018 | GEAR |
| 65 | 1 | 500964 | STUD, IDLER |
| 66 | 1 | 501017 | GEAR |
| 67 | 1 | 500939 | STUD |
| 68 | 1 | 500934 | GEAR |
| 69 | 1 | 500916 | BRACKET |
| 70 | 2 | 107407 | SCREW, CAP (1/4-20 x 1) |
| | | | |

| Item | Qty | Part # | Description |
|------|-----|----------|-----------------------------|
| 71 | 1 | 500972 | SHAFT |
| 72 | 1 | 500953 | STUD |
| 73 | 2 | 501007 | SPROCKET |
| 74 | 1 | 100600 | WASHER |
| 75 | 1 | 501010 | SPROCKET |
| 76 | 1 | 102321 | SPACER |
| 77 | 1 | 104103 | RING, SNAP |
| 78 | 1 | 500983-1 | STUD |
| 79 | 4 | 501008 | SPROCKET |
| 80 | 1 | 101924 | GEAR |
| 81 | 3 | 102303 | SPACER |
| 82 | 1 | 107632 | SCREW, SET (1/4-20 x 3/16) |
| 83 | 1 | 501019 | GEAR |
| 84 | 1 | 105311 | KEY |
| 85 | 1 | 501059 | SHAFT |
| 86 | 1 | 105302 | KEY |
| 87 | 2 | 100304 | BUSHING |
| 88 | 1 | 105315 | KEY |
| 89 | 1 | 500961 | PAWL |
| 90 | 1 | 500928 | HUB |
| 91 | 1 | 500951 | LEVER |
| 92 | 1 | 500947 | SHAFT |
| 93 | 1 | 500944 | SHAFT |
| 94 | 3 | 501093 | WASHER |
| 95 | 3 | 107306 | SCREW, HEX HD (14/20 x 3/4) |
| 96 | 1 | 101921 | GEAR |
| 97 | 1 | 101922 | GEAR |
| 98 | 1 | 101002 | GEAR |
| 99 | 1 | 101001 | GEAR |
| 100 | 1 | 500943 | SHAFT |
| 101 | 1 | 101710 | GEAR, 2-WIDE |
| 102 | 1 | 101709 | GEAR, 2-WIDE |
| 103 | 1 | 101712 | GEAR, 3-WIDE |
| 104 | 1 | 101711 | GEAR, 3-WIDE |
| 105 | 1 | 101714 | GEAR, 4-WIDE |


| 106 | |
|---|--|
| 108 1 101927 GEAR, 5-WIDE 109 1 102001 GEAR, 6-WIDE 110 1 101000 GEAR, 6-WIDE 111 1 101930 GEAR, 1-WIDE 112 1 101929 GEAR, 1-WIDE 113 1 500957 BRACKET 114 2 100309 BUSHING 115 1 501037 CAM 116 2 106710 NUT 117 1 105407 PIN 118 1 500941 YOKE 119 2 103408 FOLLOWER, CAM 120 1 500955 LINK 121 1 500936 COLLAR 122 1 102707 SPRING 123 1 107430 SCREW, CAP(10-32 x 3/4) 124 1 500927 STUD 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER | |
| 109 1 102001 GEAR, 6-WIDE 110 1 101000 GEAR, 6-WIDE 111 1 101930 GEAR, 1-WIDE 112 1 101929 GEAR, 1-WIDE 113 1 500957 BRACKET 114 2 100309 BUSHING 115 1 501037 CAM 116 2 106710 NUT 117 1 105407 PIN 118 1 500941 YOKE 119 2 103408 FOLLOWER, CAM 120 1 500955 LINK 121 1 500936 COLLAR 122 1 102707 SPRING 123 1 107430 SCREW, CAP(10-32 x 3/4) 124 1 500927 STUD 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER <td></td> | |
| 110 | |
| 111 1 101930 GEAR, 1-WIDE 112 1 101929 GEAR, 1-WIDE 113 1 500957 BRACKET 114 2 100309 BUSHING 115 1 501037 CAM 116 2 106710 NUT 117 1 105407 PIN 118 1 500941 YOKE 119 2 103408 FOLLOWER, CAM 120 1 500955 LINK 121 1 500936 COLLAR 122 1 102707 SPRING 123 1 107430 SCREW, CAP(10-32 x 3/4) 124 1 500927 STUD 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER | |
| 112 | |
| 113 1 500957 BRACKET 114 2 100309 BUSHING 115 1 501037 CAM 116 2 106710 NUT 117 1 105407 PIN 118 1 500941 YOKE 119 2 103408 FOLLOWER, CAM 120 1 500955 LINK 121 1 500936 COLLAR 122 1 102707 SPRING 123 1 107430 SCREW, CAP(10-32 x 3/4) 124 1 500927 STUD 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER | |
| 114 2 100309 BUSHING 115 1 501037 CAM 116 2 106710 NUT 117 1 105407 PIN 118 1 500941 YOKE 119 2 103408 FOLLOWER, CAM 120 1 500955 LINK 121 1 500936 COLLAR 122 1 102707 SPRING 123 1 107430 SCREW, CAP(10-32 x 3/4) 124 1 500927 STUD 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER | |
| 115 | |
| 116 2 106710 NUT 117 1 105407 PIN 118 1 500941 YOKE 119 2 103408 FOLLOWER, CAM 120 1 500955 LINK 121 1 500936 COLLAR 122 1 102707 SPRING 123 1 107430 SCREW, CAP(10-32 x 3/4) 124 1 500927 STUD 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER | |
| 117 1 105407 PIN 118 1 500941 YOKE 119 2 103408 FOLLOWER, CAM 120 1 500955 LINK 121 1 500936 COLLAR 122 1 102707 SPRING 123 1 107430 SCREW, CAP(10-32 x 3/4) 124 1 500927 STUD 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER | |
| 118 1 500941 YOKE 119 2 103408 FOLLOWER, CAM 120 1 500955 LINK 121 1 500936 COLLAR 122 1 102707 SPRING 123 1 107430 SCREW, CAP(10-32 x 3/4) 124 1 500927 STUD 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER | |
| 119 2 103408 FOLLOWER, CAM 120 1 500955 LINK 121 1 500936 COLLAR 122 1 102707 SPRING 123 1 107430 SCREW, CAP(10-32 x 3/4) 124 1 500927 STUD 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER | |
| 120 1 500955 LINK 121 1 500936 COLLAR 122 1 102707 SPRING 123 1 107430 SCREW, CAP(10-32 x 3/4) 124 1 500927 STUD 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER | |
| 121 | |
| 122 | |
| 123 | |
| 124 1 500927 STUD 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER | |
| 125 1 101923 GEAR 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER | |
| 126 1 500902 PLATE, REAR 127 2 501092 SPACER 128 1 501102 SPACER | |
| 127 2 501092 SPACER 128 1 501102 SPACER | |
| 128 1 501102 SPACER | |
| | |
| 129 2 501103 SPACER | |
| | |
| 130 1 501026 SPACER | |
| 131 1 102301 SPACER | |
| 132 1 102205 COLLAR | |
| 133 1 501110 SPACER | |
| 134 1 500983-2 STUD | |
| 135 2 107612 SCREW, SET (8-32 x 3/16) | |
| 136 1 105203 PIN, ROLL | |



3.3 LABEL FEEDING MECHANISM

| Item | Qty | Part # | Description |
|------|-----|-----------|---------------------------------|
| 1 | 4 | 104500 | RIVET |
| 2 | 1 | 190619 | PLATE, NAME |
| 3 | 14 | 107701 | SCREW, RD HD (6-32 x 1/4) |
| 4 | 1 | 500915 | PLATE BACK |
| 5 | 1 | 190211 | WIRE |
| 6 | 4 | 107417 | SCREW, CAP (10-32 X 3/8) |
| 7 | 1 | 106734 | NUT, ELASTIC STOP |
| 8 | 1 | 190002 | SOLENOID |
| 9 | 1 | 107408 | SCREW, CAP (10-32 X 1) |
| 10 | 1 | 500955REF | LINK |
| 11 | 8 | 107500 | SCREW, FLAT HD (10-32 X 1/2) |
| 12 | 1 | 500913 | PLATE, TOP |
| 13 | 1 | 500903 | PLATE, FRONT |
| 14 | 1 | 501041 | HOUSING |
| 15 | 1 | 101500 | GROMMET |
| 16 | 4 | 107702 | SCREW, RD HD (6-32 X 3/16) |
| 17 | 6 | 106800 | SCREW, BUTTON HD (1/4-20 X 3/4) |
| 18 | 1 | 500905 | KNIFE, LOWER |
| 19 | 2 | 107413 | SCREW, CAP (8-32 X 1/2) |
| 20 | 1 | 501038 | PLATE, GUIDE |
| 21 | 1 | 500908 | PLATE, KNIFE |
| 22 | 6 | 107639 | SCREW, SET |
| 23 | 1 | 501048 | PLATE, GUIDE |
| 24 | 1 | 501047 | HOLDER |
| 25 | 1 | 500987 | PLATE |
| 26 | 2 | 107511 | SCREW, FLAT HD (6-32X1/4) |
| 27 | 1 | 500904 | PLATE, BOTTOM REAR |
| 28 | 1 | 500904 | PLATE, BOTTOM FRONT |
| 29 | 1 | 102200 | COLLAR |
| 30 | 1 | 107632 | SCREW, SET (1/4-20 X 3/16) |
| 31 | 1 | 500998 | LEVER |
| 32 | 1 | 105408 | PIN, DOWEL |
| 33 | 2 | 100310 | BUSHING |
| 34 | 1 | 500986 | SPACER |
| 35 | 1 | 103105 | BEARING |


| Item | Qty | Part # | Description |
|------|-----|--------|------------------------------|
| 36 | 6 | 103106 | BEARING |
| 37 | 1 | 500958 | PULLEY |
| 38 | 1 | 500999 | SHAFT |
| 39 | 1 | 500988 | BLOCK |
| 40 | 1 | 102714 | SPRING |
| 41 | 2 | 107407 | SCREW, CAP (1/4-20 X 1) |
| 42 | 1 | 190605 | NIPPLE |
| 43 | 1 | 190606 | ELBOW |
| 44 | 1 | 500909 | BAR FEEDER |
| 45 | 6 | 107429 | SCREW, CAP (10-32 X 5/8) |
| 46 | 1 | 100117 | BUSHING |
| 47 | 1 | 107625 | SCREW, SET (10-32 X 3/8) |
| 48 | 2 | 107436 | SCREW, CAP (6-32 X 1/2) |
| 49 | 1 | 105905 | BELT, FEEDER |
| 50 | 1 | 501101 | SPACER |
| 51 | 1 | 107407 | SCREW, CAP (1/4-20 X 1 ½) |
| 52 | 1 | 100601 | WASHER |
| 53 | 1 | 501097 | BRACKET |
| 54 | 2 | 501329 | SHAFT, BELT TIGHTENER PULLEY |
| 55 | 2 | 501098 | PULLEY |
| 56 | 1 | 190649 | VALVE, SHUT OFF |
| 57 | 2 | 104100 | SNAP, RING |



3.4 MECHANISM ASSEMBLY, END PLATE

| Item | Qty | Part # | Description |
|------|-----|-------------|-----------------------------|
| 1 | 1 | 500966REF | SHAFT |
| 2 | 1 | 501030 | SHAFT |
| 3 | 1 | 500907-1REF | PLATE, END |
| 4 | 2 | 107407 | SCREW, CAP (1/4-20 X 1) |
| 5 | 1 | 500956 | LEVER |
| 6 | 3 | 100604 | WASHER |
| 7 | 1 | 102206 | COLLAR |
| 8 | 2 | 103501 | ROD, END |
| 9 | 2 | 106721 | NUT |
| 10 | -1 | 107665 | SCREW, SET (1/4-28 X 1 1/4) |
| 11 | 1 | 500963 | LEVER |
| 12 | 1 | 103408 | CAM, FOLLOWER |
| 13 | 1 | 106724 | NUT, ELASTIC STOP |
| 14 | 1 | 100129 | BUSHING |
| 15 | 1 | 106700 | NUT |
| 16 | 1 | 100601 | WASHER |
| 17 | 1 | 501020 | STUD |
| 18 | 1 | 104100 | RING, SNAP |
| 19 | 1 | 100600 | WASHER |
| 20 | 2 | 107632 | SCREW, SET (1/4-20 X 3/16) |
| 21 | 1 | 500937-1 | CAM |
| 22 | 1 | 501014 | BRACKET, CAM |
| 23 | 1 | 501025 | SPACER |
| 24 | 1 | 500946 | LEVER |
| 25 | 2 | 103105 | BEARING |
| 26 | 1 | 107404 | SCREW, CAP (1/4-20 X 1 ½) |
| 27 | 2 | 107401 | SCREW, CAP (1/4-20 X 3/4) |
| 28 | 1 | 500995REF | BRAKE, FORM |
| 29 | 1 | 107431REF | SCREW, CAP |
| 30 | 1 | 107418REF | SCREW, CAP |
| 31 | 1 | 107643REF | SCREW, CAP |
| 32 | 1 | 102215REF | COLLAR |
| 33 | 2 | 103108 | BEARING |
| 34 | 1 | 501013 | BLOCK, RATCHET |
| 35 | 1 | 107670 | SCREW, SET (1/4-20 X 1) |


| Item | Qty | Part # | Description |
|------|-----|--------|----------------------------|
| 36 | 1 | 502842 | KNOB |
| 37 | 3 | 107622 | SCREW, SET (10-32 X 3/16) |
| 38 | 1 | 500917 | RATCHET |
| 39 | 1 | 107428 | SCREW, CAP (1/4-20 X 5/8) |
| 40 | 1 | 107602 | SCREW, SET (6-32 X 1/4) |
| 41 | 1 | 501043 | PAWL, RATCHET |
| 42 | 1 | 102700 | SPRING |
| 43 | 1 | 501024 | HOUSING, SPRING |
| 44 | 1 | 107674 | SCREW, SET (10-34 X 1 1/4) |
| 45 | 1 | 106710 | NUT |
| 46 | 1 | 102114 | KNOB |



3.5 FORM INDEX, LABELING HEAD


| 1 4 107430 SCREW, CAP (10-32 X 3/4) 2 1 501053 HUB, PINWHEEL 3 32 500962 PINWHEEL 4 2 500929 RIM, PINWHEEL 5 1 501054 HUB, PINWHEEL 6 6 107632 SCREW, SET (1/4-20 X 3/16) 7 8 107623 SCREW, SET (10-32 X 1/4) 8 6 501108 ROLLER, PAPER FEED 9 1 500906 PLATE, CENTER 10 4 107643 SCREW, SET (5/16-18 X 1/4) 11 1 500908REF PLATE, KNIFE 12 6 501091 GUIDE, PAPER 13 4 501029 HUB 14 4 501028 RIM, HUB 15 2 501084 BRACKET | | |
|---|----------------------------|--|
| 3 32 500962 PINWHEEL 4 2 500929 RIM, PINWHEEL 5 1 501054 HUB, PINWHEEL 6 6 107632 SCREW, SET (1/4-20 X 3/16) 7 8 107623 SCREW, SET (10-32 X 1/4) 8 6 501108 ROLLER, PAPER FEED 9 1 500906 PLATE, CENTER 10 4 107643 SCREW, SET (5/16-18 X 1/4) 11 1 500908REF PLATE, KNIFE 12 6 501091 GUIDE, PAPER 13 4 501029 HUB 14 501028 RIM, HUB | | |
| 4 2 500929 RIM, PINWHEEL 5 1 501054 HUB, PINWHEEL 6 6 107632 SCREW, SET (1/4-20 X 3/16) 7 8 107623 SCREW, SET (10-32 X 1/4) 8 6 501108 ROLLER, PAPER FEED 9 1 500906 PLATE, CENTER 10 4 107643 SCREW, SET (5/16-18 X 1/4) 11 1 500908REF PLATE, KNIFE 12 6 501091 GUIDE, PAPER 13 4 501029 HUB 14 501028 RIM, HUB | HUB, PINWHEEL | |
| 5 1 501054 HUB, PINWHEEL 6 6 107632 SCREW, SET (1/4-20 X 3/16) 7 8 107623 SCREW, SET (10-32 X 1/4) 8 6 501108 ROLLER, PAPER FEED 9 1 500906 PLATE, CENTER 10 4 107643 SCREW, SET (5/16-18 X 1/4) 11 1 500908REF PLATE, KNIFE 12 6 501091 GUIDE, PAPER 13 4 501029 HUB 14 4 501028 RIM, HUB | PINWHEEL | |
| 6 6 107632 SCREW, SET (1/4-20 X 3/16) 7 8 107623 SCREW, SET (10-32 X 1/4) 8 6 501108 ROLLER, PAPER FEED 9 1 500906 PLATE, CENTER 10 4 107643 SCREW, SET (5/16-18 X 1/4) 11 1 500908REF PLATE, KNIFE 12 6 501091 GUIDE, PAPER 13 4 501029 HUB 14 4 501028 RIM, HUB | RIM, PINWHEEL | |
| 7 8 107623 SCREW, SET (10-32 X 1/4) 8 6 501108 ROLLER, PAPER FEED 9 1 500906 PLATE, CENTER 10 4 107643 SCREW, SET (5/16-18 X 1/4) 11 1 500908REF PLATE, KNIFE 12 6 501091 GUIDE, PAPER 13 4 501029 HUB 14 4 501028 RIM, HUB | HUB, PINWHEEL | |
| 8 6 501108 ROLLER, PAPER FEED 9 1 500906 PLATE, CENTER 10 4 107643 SCREW, SET (5/16-18 X 1/4) 11 1 500908REF PLATE, KNIFE 12 6 501091 GUIDE, PAPER 13 4 501029 HUB 14 4 501028 RIM, HUB | | |
| 9 1 500906 PLATE, CENTER 10 4 107643 SCREW, SET (5/16-18 X 1/4) 11 1 500908REF PLATE, KNIFE 12 6 501091 GUIDE, PAPER 13 4 501029 HUB 14 4 501028 RIM, HUB | | |
| 10 4 107643 SCREW, SET (5/16-18 X 1/4) 11 1 500908REF PLATE, KNIFE 12 6 501091 GUIDE, PAPER 13 4 501029 HUB 14 4 501028 RIM, HUB | | |
| 11 1 500908REF PLATE, KNIFE 12 6 501091 GUIDE, PAPER 13 4 501029 HUB 14 4 501028 RIM, HUB | | |
| 12 6 501091 GUIDE, PAPER 13 4 501029 HUB 14 4 501028 RIM, HUB | | |
| 13 4 501029 HUB 14 4 501028 RIM, HUB | | |
| 14 4 501028 RIM, HUB | | |
| • | | |
| 15 2 501084 BRACKET | | |
| | | |
| 16 2 100323 BUSHING | BUSHING | |
| 17 2 501106 SHAFT | SHAFT | |
| 18 4 102215 COLLAR | COLLAR | |
| 19 12 107409 SCREW, CAP (10-32 X 1/2) | | |
| 20 2 500942 ARM KNIFE | ARM KNIFE | |
| 21 2 107429 SCREW, CAP (10-32 X 5/8) | SCREW, CAP (10-32 X 5/8) | |
| 22 2 103105 BEARING | | |
| 23 2 500950 STUD, KNIFE ARM | | |
| 24 1 501030 SHAFT, PINWHEEL | | |
| 25 2 105318 KEY | KEY | |
| 26 1 107406 SCREW, CAP (10-32 X 1 ¹ / ₄) | SCREW, CAP (10-32 X 1 1/4) | |
| 27 1 500995 BRAKE, FORM | BRAKE, FORM | |
| 28 3 107408 SCREW, CAP (10-32 X 1) | | |
| 29 1 500907 PLATE, END | | |
| 30 2 106710 NUT | | |
| 31 1 503275 SHAFT | | |
| 32 2 501190 DRIVE, HUB BELT | DRIVE, HUB BELT | |
| 33 1 500930 HUB, RIM | HUB, RIM | |
| 34 2 107417 SCREW, CAP (10-32 X 3/8) | | |
| 35 2 100606 WASHER | | |

| Item | Qty | Part # | Description | |
|------|-----|--------|-------------------------|--|
| 36 | 1 | 501042 | BRACKET | |
| 37 | 1 | 190100 | MICROSWITCH | |
| 38 | 2 | 107700 | SCREW, RD HD (6-32,X,1) | |
| 39 | 1 | 190203 | COVER | |
| 40 | 1 | 500966 | SHAFT, KNIFE ARM | |
| 41 | 2 | 501195 | HUB, BELT PULLEY | |
| 42 | 2 | 501193 | ARM, FEED ROLLER | |
| 43 | 2 | 100309 | BUSHING | |
| 44 | 1 | 501194 | SHAFT, FORM DRIVE | |
| 45 | 2 | 107002 | BOLT, SHOULDER (1/4) | |
| 46 | 2 | 501192 | PULLEY, BELT TAKE-UP | |
| 47 | 2 | 100114 | BUSHING | |
| 48 | 2 | 501191 | PULLEY, O-RING BELT | |
| 49 | 2 | 100300 | BUSHING | |
| 50 | 2 | 107101 | BOLT, SHOULDER (5/16) | |
| 51 | 2 | 190647 | O-RING | |
| 52 | 10 | 190646 | O-RING | |
| 53 | 2 | 501334 | SLEEVE | |




3.6 UPPER KNIFE LABELING HEAD

| Item | Qty | Part # | Description | |
|------|-----|----------|-------------------------------|--|
| 1 | 4 | 107503 | SCREW, FLAT HD (1/4-20 X 5/8) | |
| 2 | 1 | 501033 | PLATE | |
| 3 | 12 | 107321 | SCREW, HEX HD (10-32 X 1/2) | |
| 4 | 6 | 107430 | SCREW, CAP (10-32 X 3/4) | |
| 5 | 1 | 500901-1 | HOLDER | |
| 6 | 1 | 500912 | KNIFE | |
| 7 | 1 | 501044 | PLATE | |
| 8 | 2 | 102705 | SPRING | |
| 9 | 1 | 500938 | BRACKET | |
| 10 | 2 | 107409 | SCREW, CAP (10-32 X 1/2) | |
| 11 | 2 | 103104 | BEARING | |
| 12 | 1 | 501057 | ROLLER | |
| 13 | 1 | 107401 | SCREW | |
| 14 | 1 | 500903 | PLATE | |



3.7 LABEL & MARGIN SLITTER ASSEMBLY


| Item | Qty | Part # | Description | |
|------|-----|--------|---|--|
| 1 | 1 | 500924 | BRACKET, KNIFE HOLDER LH | |
| 2 | 12 | 100116 | BUSHING | |
| 3 | 6 | 102704 | SPRING | |
| 4 | 6 | 501109 | SCREW, SPRING ADJUSTING | |
| 5 | 12 | 102117 | KNOB | |
| 6 | 6 | 107674 | SCREW, SET (10-32 X 1 ¹ / ₄) | |
| 7 | 6 | 500965 | LEVER, KNIFE | |
| 8 | 4 | 107437 | SCREW, CAP (6-32 X 3/8) | |
| 9 | 1 | 501079 | GUIDE, PAPER LH | |
| 10 | 6 | 106900 | BOLT, SHOULDER | |
| 11 | 6 | 100609 | WASHER | |
| 12 | 12 | 103203 | BEARING | |
| 13 | 6 | 501039 | KNIFE, CIRCULAR | |
| 14 | 6 | 106726 | NUT | |
| 15 | 2 | 107438 | SCREW, CAP (10-32 X 1/4) | |
| 16 | 2 | 500984 | GUIDE, PAPER STRIPPER | |
| 17 | 2 | 105405 | PIN, DOWEL | |
| 18 | 2 | 501090 | BRACKET, PAPER STRIPPER | |
| 19 | 4 | 500925 | BRACKET, KNIFE HOLDER | |
| 20 | 12 | 107321 | SCREW, HEX (10-32 X 1/2) | |
| 21 | 4 | 501082 | GUIDE, PAPER | |
| 22 | 1 | 500926 | BRACKET, KNIFE HOLDER RH | |
| 23 | 1 | 501079 | GUIDE, PAPER RD | |
| 24 | 1 | 500967 | SHAFT | |
| 25 | 1 | 107428 | SCREW, CAP (1/4-20 X 5/8) | |
| 26 | 3 | 107708 | SCREW, BUTTON HEAD (6-32 X 3/16 | |
| 27 | 1 | 501081 | SCALE | |



3.8 BOX GLUE ASSEMBLY, LABELING HEAD

| Item | Qty | Part # | Description | |
|------|-----|-----------|--|--|
| 1 | 1 | 107662 | SCREW, SET (10-32 X 3/16) | |
| 2 | 1 | 102114 | KNOB | |
| 3 | 1 | 102210 | COLLAR | |
| 4 | 1 | 102708 | SPRING | |
| 5 | 1 | 106710 | NUT | |
| 6 | 2 | 501104 | SCREW, ADJUSTING | |
| 7 | 2 | 501105 | NUT | |
| 8 | 1 | 105612 | SCREW, HR HS (10-32 X 4) | |
| 9 | 2 | 108107 | SCREW, CAP (8-32 X 1/2) | |
| 10 | 1 | 500973 | BLOCK, SCRAPER MTG | |
| 11 | 1 | 500982 | BRACKET, GLUE BOX HOLDER | |
| 12 | 2 | 108109 | SCREW, CAP (10-32 X 1/2) | |
| 13 | 1 | 500914 | SCRAPER, 1" | |
| 14 | 1 | 500919 | SCRAPER, 1 ½" | |
| 15 | 1 | 500920 | SCRAPER, 2" | |
| 16 | 1 | 500921 | SCRAPER (ALL) | |
| 17 | 1 | 190624 | GLUE BOTTLE | |
| 18 | 2 | 190628 | NUT, GLUE BOTTLE | |
| 19 | 1 | 190623 | CAP, GLUE BOTTLE | |
| 20 | 1 | 190626 | PIPE, GLUE BOTTLE | |
| 21 | 1 | 190627 | PIPE | |
| 22 | 1 | 190635 | NUT | |
| 23 | 1 | 501056 | BLOCK, GLUE FILL | |
| 24 | 3 | 108102 | SCREW, CAP (1/4-20 X 5/8) | |
| 25 | 1 | 108110 | SCREW, CAP (1/4-20 X 1 ³ / ₄) | |
| 26 | 1 | 500910 | GLUE BOX | |
| 27 | 1 | 102707 | SPRING | |
| 28 | 2 | 501066 | STAINLESS STEEL PIN | |
| 29 | 4 | 501074 | STRIPPER | |
| 30 | 1 | 501040 | WASHER | |
| 31 | 1 | 500969 | GLUE WHEEL, 1" | |
| 32 | 1 | 500970 | GLUE WHEEL, 1 ½" | |
| 33 | 1 | 500971 | GLUE WHEEL, 2" | |
| 34 | 1 | 500935REF | GLUE WHEEL SHAFT | |
| 35 | 1 | 105313 | KEY | |

| Item | Qty | Part # | Description | |
|------|-----|-----------|---------------------------|--|
| 36 | 1 | 105302REF | KEY | |
| 37 | 2 | 107623REF | SCREW, SET (10-32 X 1/4) | |
| 38 | 1 | 501009REF | SPROCKET, 35B10 | |
| 39 | 1 | 107903 | PLUNGER, BALL (1/4-20) | |
| 40 | 1 | 501062 | NUT, RETAINER | |
| 41 | 1 | 501063 | ROD, NUT | |
| 42 | 1 | 105400 | PIN | |
| 43 | 1 | 501070 | HOLDER | |
| 44 | 1 | 106721 | NUT | |
| 45 | 1 | 501071 | SHAFT, STRIPPER | |
| 46 | 1 | 105427 | PIN, DOWEL | |
| 47 | 4 | 107612 | SCREW, SET (8-32 X 3/16) | |
| 48 | 1 | 105431 | PIN, DOWEL | |
| 49 | 1 | 107622REF | SCREW, SET (10-32 X 3/16) | |
| 50 | 1 | 106720 | NUT, HEX | |



KR 211E LABELING HEAD 4

THE FOLLOWING PAGES ARE FOR THE KR211E LABELING HEAD.

4.1 **ELECTRONIC INDEXER**

Description: The electronic indexer is a drive system for indexing the mailing list through the labeling head in very precise increments. This system replaces the manual ratchet assembly. All paper movements in this direction are made with push button or proximity switch control.

The stepping motor moves in increments called steps. Label sizes are set with decade thumb wheel switches in steps per inch. Controls are provided for on-off, forwardreverse, index, jog, and single step.

Front Panel Controls: ON-OFF—Applies power to stepping motor drive. FWD-REV— Determines direction of stepping motor rotation. JOG—The jog pushbutton will allow the motor to continuously step at a slow rate. SINGLE STEP—The single step push button allows the motor to move one step. DECADE THUMBWHEEL—The threedecade thumbwheel switch determines how many steps the stepping motor moves for one index.

Set-up: Mechanical Knife Head

- 1. Advance the labeling head so that the knife is in the up position and has just cleared the lower knife and paper guide.
- 2. Set the magnet ring on the knife cam to operate the proximity switch.
- 3. Insert the mailing list on to the pinwheels of the labeling head.
- 4. Using the JOG push button move the mailing list through the slitter knives and the guillotine knife.
- 5. Align the mailing list with the proper cut position between labels using the FWD-REV and single step push button.
- 6. Set the decade thumbwheel switch for correct number of steps for the label size.

Set-up: Electronic Knife Clutch Head

- 1. Advance head until label vacuum belt just starts to move.
- 2. Set magnet under knife proximity switch.
- 3. Cycle machine. Knife should cut just as belt stops. Move magnet for fine adjustment.
- 4. Set paper proximity switch magnet a few degrees in front of knife magnet.

4.2 LABEL SIZE CHART

Pulley Combination: 25 on motor

48 on Pinwheel Shaft

48 step/inch

Thumbwheel Setting: 48 multiplied by label size (inches)

4" = 1921" = 482" = 96 $\frac{1}{2}$ " = 24

3" = 1445-2/3" = 272

1-1/2" = 72 5/8" = 30


6" = 288

4.3 PROBLEM DIAGNOSTIC GUIDE

Test Lights: Indexer

- 1. Motor Oscillator: The light will be on when the power is turned on. The single step switch causes the light to go off. When the single step is released the light will come back on.
- 2. Main Oscillator: The light will be on when power is turned on. The JOG push button will turn the light off. When the JOG push button is released the light will be on.
- 3. Power-up: This light will come on when power is applied to the board.
- 4. Motor Drive: This light will be on for the period of an index or a jog for as long as the single step is held. The light will not be as bright on JOG and INDEX as on SINGLE STEP.
- 5. Index: This light will come on when the proximity switch is activated.

Adjust motor speed potentiometer for the speed at which the motor indexes reliably at operating machine speed.




4.4 PROBLEM DIAGNOSTICS

| Problem | Possible Cause | Correction |
|---|---|--|
| Inconsistent label size | Motor stalling | Adjust motor speed |
| | | Reduce drag on paper |
| Motor will not step | Logic board | Perform indicator light check. Replace logic board if test fails. |
| | -20 VDC Power Supply | Replace power supply |
| | Defective STM1800C Translator | Replace translator |
| Motor steps with push buttons but not with proximity switch | Proximity switch not close enough to magnet | Adjust switch |
| | Defective switch | Replace switch |
| | Defective magnet | Replace magnet |
| | Magnet inserted in wrong direction | Proximity switch operates with the South Pole. The North Pole is marked in red. Rotate magnet and re-insert. |

4.5 PARTS & DIAGRAMS


| Item | Qty_ | Part # | Description |
|------|------|-----------|---------------------|
| 1 | 1 | 101102 | BEARING, ONE-WAY |
| 2 | 1 | 102220 | COLLAR, 0.750 ID |
| 3 | 2 | 103104 | BEARING, FLAT |
| 4 | 3 | 103108 | BEARING, FLAT |
| 5 | 4 | 103112 | BEARING, FLAT |
| 6 | 1 | 103116 | BEARING, FLAT 1.000 |
| 7 | 2 | 103803 | BEARING, HUB |
| 8 | 2 | 103812 | BEARING, HUB |
| 9 | 1 | 104020 | CLUTCH, WARNER |
| 10 | 1 | 108736 | PULLEY, 25L037 |
| 11 | 1 | 108737 | PULLEY, 48L037 |
| 12 | 1 | 108765 | PULLEY, 60XL037 |
| 13 | 1 | 109003 | BELT, 140XL037 |
| 14 | 1 | 109009 | BELT, 24 XL037 |
| 15 | 1 | 200164 | MOTOR |
| 16 | 2 | 201048 | MAGNET |
| 17 | 2 | 500901-2 | HOLDER, UPPER KNIFE |
| 18 | 1 | 500902 | PLATE, REAR |
| 19 | 1 | 500903 | PLATE, FRONT |
| 20 | 1 | 500906-3 | PLATE, CENTER |
| 21 | 1 | 500907-3 | PLATE, END |
| 22 | 1 | 500912 | KNIFE, UPPER |
| 23 | 1 | 500928 | HUB |
| 24 | 1 | 500936 | COLLAR |
| 25 | 1 | 500938 | BRACKET, ROLLER |
| 26 | 1 | 500941 | YOKE |
| 27 | 1 | 500943 | SHAFT, KNIFE DRIVE |
| 28 | 1 | 500945-1A | SHAFT, CRANK DRIVE |
| 29 | 1 | 500957 | BRACKET, YOKE |
| 30 | 1 | 500960-4 | PULLEY |
| 31 | 1 | 500981-1A | SHAFT, DRIVE ASSY |
| 32 | 1 | 500995 | BRAKE |
| 33 | 1 | 501022 | SPACER |
| 34 | 1 | 501023 | HUB, BEARING |
| 35 | 1 | 501030-2 | SHAFT, PINWHEEL |

| Item | Qty | Part # | Description |
|------|-------|----------|--------------------------|
| 36 | 1 | 501032 | HUB, BEARING |
| 37 | 1 | 501033 | PLATE, GUIDE LH |
| 38 | 1 | 501037 | CAM |
| 39 | 1 | 501044 | PLATE, GUIDE RH |
| 40 | 1 | 501057 | ROLLER |
| 41 | 2 | 501193 | ARM, FEED ROLLER |
| 42 | 1 | 501194-1 | SHAFT, FORM DRIVE |
| 43 | 2 | 501374-1 | RING, MAGNET |
| 44 | 1 | 501382-1 | PLATE, MOTOR MOUNT |
| 45 | 1 | 501383 | PLATE, MOTOR MOUNT |
| 46 | 2 | 501403 | BRACKET, ECCENTRIC SHAFT |
| 47 | 2 | 501404 | ARM |
| 48 | 2 | 501405 | BRACKET, KNIFE HOLDER |
| 49 | 1 | 501412 | SHAFT, ECCENTRIC |
| 50 | 1 | 501413 | PLUG, END PLATE |
| 51 | 1 | 501414 | PULLEY, 30XL037 |
| 52 | 1 | 501415 | CLAMP, CLUTCH |
| 53 | REQ'D | 501417 | SPACER |
| 54 | 1 | 501418 | PLATE, CLUTCH LOCKING |
| 55 | 1 | 504842-2 | BRACKET |




| KIRK-RUDY, INC. Kennesaw.cedrgia | | PLATE ASS'Y | | DMC.NG. 501400 | | |
|-------------------------------------|------|-------------|---|-------------------|-----------------|--|
| | | | | DATE 11-08-90 | DRAWN BY NAJ | |
| S | ВҮ | NAJ | | | | |
| REVISIONS | DATE | 11-20-92 | | | | |
| | NO. | | 2 | 3 | 4 | |
| | | | | | | |

FILENAME, 501400,1exp



FILENAME: 501400,18×p



SEQUENCE OF OPERATION

- A. PBI TURNED, POWER APPLIED TO CONTROLS.
- B. PBZ SELECTS FOWARD/REVERSE
- C. BCD SWITCH SELECTS # OF STEPS OF MOTOR FOR EACH INDEX
- D. PB3, JOG ALLOWS MOTOR TO MOVE CONTINOUSLY.
- E PB4, SINGLESTEP MOVES MOTOR ONE STEP
- F. LSI, MOUNTED NEAR KNIFE CAM (WITH MAGNET) INDEXES MOTOR AFTER EACH KNIFE OPERATION.

| PLI, PIN# | BCD | SWITCH |
|----------------------------|-----|----------|
| A_{i} | 1 | UNITS |
| 2 | 2 | |
| 2 3 4 5 6 7 | 4 | |
| 4 | 8 | |
| 5 | 1 | TENS |
| 6 | 2 | |
| 7 | 4 | |
| .8 | 8 | |
| 9 | 1 | HUNDREDS |
| 10 | 2 | |
| 11. | 4 | |
| 12 | 8 | |
| | | |

PLZ, PINT

1


12 YDC


PL4 6 PIN TRW CINCH CONNECTOR

| 3 | ۵ | u. | 2 | | | Z O | Ī |
|-------|-----------|------|--------|-------|-------|---------|-----------|
| | | | | | | DATE | REVISIONS |
| | | 2000 | | | | ВҮ | NS |
| SHARP | UNLESS OT | 360 | FINISH | +1/64 | PRAC. | UNLESSO | DIMENSIO |

5.Ω 225 w \ 5

For 5A and 5B






REVISEORS


TOTAL COME STATEMENT AND THE STATEMEN

3. IO. 275-W ADJUSTABLE REGISTOR USED FOR MORE FLI STEPHOTOR.


2. FUSE CHANGED TO SADL


6






* REVISIONS OF DWG, #210341 INDEXER LOGIC 4-15-83 DLL







MICRO SWITCH


a Honeywell Division

Installation instructions for 103SR Series Hall effect position sensors

PK 87553

GENERAL INFORMATION

103SR Series Hall effect position sensors are completely sealed in threaded aluminum bushings, and meet NEMA 3, 3R, 3S, 4, 4X, 6, 12 and 13 requirements. The output can be directly interfaced with most electronic circuitry such as microprocessors, integrated logic, discrete transistors and SCRs, providing voltage and current requirements are compatible.



ELECTRICAL SPECIFICATIONS

| Supply | Supply | | Output | Output | Catalog Listir | | |
|------------------|-------------------|---|----------------------------------|----------------|--------------------------|---------------------|-------------------|
| Voltage (VDC) | Current (mA max.) | Output Type | Voltage (V) | Current (max.) | 6" stranded leadwires | 1 meter jacketed | Magnetics Type |
| 4.5 to 5.5 | 4.0 | Sink | 0.4 | 8mA | 103SR5A-1 | 103SR5A-2 | Unipolar |
| | | Source | (Vs-1.5) | 20mA | 103SR11A-1 | 103SR11A-2 | |
| 6 to 16 | 13.0 | , | | | 103SR12A-1 | 103SR12A-2 | |
| | | Sink | 0.4 | | 103SR13A-1 | 103SR13A-2 | |
| | | | | | 103SR17A-1 | 103SR17A-2 | Bipolar |
| 4 to 10 | 3.5 | Linear Source | 1.75 to 2.25 V @ 5 V, 0 gauss | | 103SR3F-5** | • | à la c |

MAGNETIC CHARACTERISTICS

| | . • Magnetic gauss characteristics & temperature | | | | | | | | | |
|---------------------|--|--------------|-------------|-------------|---------------|-----------------|------|--------------|------|--|
| | 0 to 70° C | | | _ | -40 to 100° C | | | 25°C Typical | | |
| Catalog listings | Max. op. | Min. rel. | Min. df. | Max. op. | Min. ret. | Min. dif. | Typ. | Typ. rel. | Typ. | |
| 103SR11A-1 | 735 | 25 | 50 | | | | 350 | 215 | 135 | |
| 103SR5A-1 | 735 | 25 | 50 | | | | 350 | 215 | 135 | |
| 103SR12A-I | 475 | 135 | 40 | 495 | 40 | 40 | 330 | 245 | 85 | |
| 103SR13A-1 | 475 | 135 | 40 | 495 | 40 | 35 | 330 | 245 | 85 | |
| 103SR17A-1 | 180 | -180 | 40 | 205 | -205 | 35 | 50 | -50 | 100 | |
| 103SR3F-5 | (-400 to +4 | 00 gauss) | 0.75 to 1.0 | % mV/gau | ss | *************** | | | | |

Bipolar sensor, magnetic: a Hall effect sensor that has a plus (South pole) maximum operate point, and a minus (North pole) minimum release point. Operate and release points can be both positive or both negative. Therefore, latching cannot be guaranteed. Ring magnets are usually used with bipolar sensors.

Unipolar sensor, magnetic: A Hall effect sensor that has a plus maximum operate point, and a plus minimum release point. One magnetic pole (South) is required to operate and release a unipolar sensor.

*Leadwire length:

- -1 152,4mm (6.0 in.), Type 1
- -2 1 meter (39.37 in.), Type 2 -3 1,52 meter (60.0 in.), Type 1
- -4 304,6mm (12.0 in.) Type 1
- -5 4,57 meter (180 in.), Type 1
- -6 3,05 meter (120 in.). Type 1
- -8 1 meter (39.37 in.), Type 2, stainless steel bushing

Leadwire type:

Type 1 - 22 gage stranded, teflon insulated Type 2 - 22 gage PVC insulated conductors with yellow molded PVC jacket

"Linear listing - 152,4mm (6.0 in.), Type 1
Contact local sales office for other listings. All leadwire types and lengths not established for all other listings.

CAUTION

DO NOT reverse supply voltage polarity.

DO NOT exceed maximum ratings.

Positive gauss represents the South pole of the magnet facing and sensing area. Negative gauss represents the North pole of the magnet facing the sensing area.

ABSOLUTE MAXIMUM RATINGS*

| Parameters | 4.5 to 5.5VDC | 6 to 16VDC |
|--|-----------------------------|-----------------------------|
| Supply Voltage (Vs) | -1.2 to +10VDC | -1.2 to +20VDC |
| Voltage Externally Applied to Output | +10VDC max. (OFF only) | +20VDC max. (OFF only) |
| | -0.5VDC min. (ON or Off) | -0.5VDC min. (ON or OFF) |
| Output Current | 20mA | 40mA |
| Temperature, Operate and Storage | -40° C to +100° C (| -40° F to +212° F) |

^{*}Performance at maximum ratings cannot be guaranteed. However, sensors will not be damaged unless these ratings are exceeded.

PROXIMITY SWITCH 210255

TROUBLE SHOOTING

If sensor does not operate, follow these steps:

- 1. Make certain all wiring is correct. Load must be connected.
- Measure supply voltage across Red (+) and Black (-) leads to verify that proper supply voltage is present.
- Connect positive lead of voltmeter to the Blue (output) lead and the negative lead of the voltmeter to the Black (ground) lead. With magnet removed (or north-pole present), reading should be:

| 103SR5A-1 | Vs |
|------------|-----|
| 103SR11A-1 | 0 |
| 103SR12A-1 | . 0 |
| 103SR13A-1 | Vs |
| 103SR17A-1 | Vs |

When magnet (south pole) is moved toward sensing face (beyond operating point), the output should change state. Reading should be:

| 103SR5A-1 | .4V max. |
|-------------|--------------|
| 103SR11A-1 | 3.4V min. |
| 103SR12A-1 | (Vs-2)V min. |
| 103SR13A-1 | .4V max. |
| 103SR17A-1° | .4V max. |

*North magnetic pole must be present to assure device is OFF due to bipolar magnetic operation.

NEMA RATINGS NON-HAZARDOUS LOCATIONS

Type 3 enclosure — intended for outdoor use primarily to provide a degree of protection against windblown dust, rain, sleet, and external ice formation.

Type 3R enclosure — intended for outdoor use primarily to provide a degree of protection against falling rain, sleet, and external ice formation.

Type 4 enclosure — intended for indoor or outdoor use primarily to provide a degree of protection against windblown dust and rain, splashing water, and hose-directed water.


Type 4X enclosure — intended for indoor or outdoor use primarily to provide a degree of protection against corrosion, windblown dust and rain, splashing water, and hose-directed water.

Type 6 enclosure — intended for indoor or outdoor use primarily to provide a degree of protection against the entry of water during occasional temporary submersion at a limited depth.


Type 12 enclosure — intended for indoor use primarily to provide a degree of protection against dust, falling dirt, and dripping noncorrosive liquids.

Type 13 enclosure — intended for indoor use primarily to provide a degree of protection against dust, spraying of water, oil, and noncorrosive coolant.

1SR15 MOUNTING BRACKET



38PA1-SR BUSHING



Warranty/Remedy

Seller warrants its products to be free from defects in design, material and workmanship under normal use and service. Seller will repair or replace without charge any such product it finds to be so defective on its return to Seller within 18 months after date of shipment by Seller. The foregoing is in lieu of all other expressed or implied warranties (except of title), including those of merchantability and fitness for a particular purpose. The foregoing is also purchaser's sole remedy and is in lieu of all other guarantees, obligations, or liabilities or any consequential, incidental, or punitive damages attributable to negligence or strict liability, all by way of example.

While we provide application assistance on MICRO SWITCH products, personally and through our literature, it is up to the customer to determine the suitability of the product in the application.

MICRO SWITCH PK 8909 2

PERMANENT MAGNET

This Permanent Magnet is designed for use with MICRO SWITCH magnetically operated solid state switches. It is fully magnetized before shipping and is ready to use.

(The North Magnetic Pole is marked N, + or a Red Color)*

CAUTION


- To prevent shifting the magnetic pole location and demagnetizing the magnet slightly, avoid contact or close proximity between magnets or other ferromagnetic objects. Any demagnetization or shifting of the pole location will have an appreciable effect on the operate and release distances from the face of the magnet to surface of the switch.
- 2. Don't force the like poles of two magnets together, as contact in a repelling position will partially demagnetize them.
- 3. Never separate two contacting magnets with unlike poles together by sliding in the direction of magnetization, as this will cause a drastic reduction in magnetization. Separate with a direct pull.
- * Ref: American Society for Testing Materials (ASTM)


MICRO SWITCH


A DIVISION OF HONEYWELL


PK 8909 2 874 PRINTED IN USA

210256









| 5 | NOTES | | |
|---|-------|------|------|
| | | | |
| | | | |
| • | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| *************************************** | | | |
| | | | |
| | | | |
| 4444 | | - 1, | |
| | | | |

13 WARRANTY AND SERVICE

WARRANTY

Warranty: Kirk-Rudy, Inc., warrants to the original retail purchaser that this product is free from defects in the material and workmanship, and agrees to repair or replace, at Kirk-Rudy's option, any defective product within (90) days from the date of purchase. This warranty is not transferable. It covers damage resulting from defects in material or workmanship, and it does not cover conditions or malfunctions resulting from normal wear, neglect, abuse or accident.

THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESSED WARRANTIES ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY IMPLIED WARRANTY ARISING OUT OF A COURSE OF DEALING, CUSTOM, OR USAGE OF TRADE.

Limitation of Remedies: If product is proven to be defective within the warranty period stated above, THE EXCLUSIVE REMEDY, AT KIRK-RUDY'S OPTION, SHALL BE TO REFUND THE PURCHASE PRICE OF OR TO REPAIR OR REPLACE THE DEFECTIVE PRODUCT, provided that the defective product is, at Kirk-Rudy's choice, returned immediately to Kirk-Rudy or authorized service representative designated by Kirk-Rudy, or made available at user's premises in a location suitable for servicing.

Limitation of Liability: Kirk-Rudy shall not otherwise be liable for any losses or damages, whether direct, indirect, special, incidental, or consequential, regardless of the legal or equitable theory asserted, including contract, negligence, warranty, or strict liability.

To obtain replacement parts and service, contact an Authorized Kirk-Rudy Dealer. Use Kirk-Rudy part numbers when ordering.

USE ONLY GENUINE KIRK-RUDY REPLACEMENT PARTS

KIRK-RUDY, INC 125 LORRAINE PARKWAY WOODSTOCK, GA 30188 PH 770-427-4203 FX 770-427-4036